



使用说明书
玉环环洋电气制造厂

玉环环洋电气制造厂
YUHAN HUANYANG ELECTRIC FACTORY

区域总代理

目 录

一、前言	2
1、购入时注意事项	2
2、HY系列铭牌说明	2
二、安全使用注意事项	3
1、送电前	3
2、送电中	4
3、运转中	4
三、产品标准规格	5
1、产品个别规格	5
2、产品通用规格	6
四、储存及安装	7
1、储存	7
2、安装场所及环境	8
3、安装空间与方向	8
五、配线	8
1、主回路配线图	9
2、接线端子说明	9
3、基本配线图	12
4、配线注意事项	12
六、数位操作器说明	14
1、数位操作器说明	14
2、操作范例说明	16
七、试运行	17
1、运行前重点检查	17
2、试运行方法	17
八、功能一览表	17
九、功能说明	18
十、保养维护、故障信息及排除方法	18
1、维护检查注意事项	60
2、定期检查项目	60
3、故障信息及排除方法	60
4、故障及分析	63
十一、周边设施选用配置	63
1、选件	64
2、配置	65
用户参数设定表	67

*因公司产品更新，本册内容若有更改，恕不另行通知。



使用说明书

I. Introduction

Thank you for purchasing and using the general-purpose inverter of HY series of multi-functions and high performance.

Please read carefully the operation manual before putting the inverter to use so as to correctly install and operate the inverter, give full play to its functions and ensure the safety. Please keep the operation manual handy for future reference, maintenance, inspection and repair.

Due to the inverter of a kind of electrical and electronic product, it must be installed, tested and adjusted with parameters by specialized engineering persons or motors.

The marks of **Danger**, **Caution**, **Attention** and other symbols in the manual remind you of the safety and prevention cautions during the handling, installation, running and inspection. Please follow these instructions to make sure the safe use of the inverter. In case of any doubt, please contact our local agent for consultation. Our professional persons are willing and ready to serve you.

The manual is subject to change without notice.

Danger indicates wrong use may kill or injure people.


Caution indicates wrong use may damage the inverter or mechanical system.

1. Checks upon Delivery

The inverter has been strictly and well packed before ex-work. In consideration of various factors during the transportation, special attention should be paid to the following points before the assembly and installation. If there is anything abnormal, please notify the dealer or the relevant people of our company.

- Check if the inverter has got any damage or deformation during the transportation and handling.
- Check if there is one piece of HY series inverter and one copy of the instruction manual available when unpacking it.
- Check the information on the nameplate to see if the specifications meet your order (Operating voltage and KVA value).
- Check if there is something wrong with the inner parts, wiring and circuit board.
- Check if each terminal is tightly locked and if there is any foreign article inside the inverter.
- Check if the operator buttons are all right.
- Check if the optional components you ordered are contained.

2. Nameplate Description of HY Series Inverter



A Caution


- Be sure to turn off the input power supply before wiring.
- Do not touch any internal electrical circuit or component when the charging lamp is still on after the AC power supply is disconnected, which means the inverter still has high voltage inside and it is very dangerous.
- Do not check components and signals on the circuit boards during the operation.
- Do not disassemble or modify any internal connecting cord, wiring or component of the inverter by yourself.
- Be sure to make correct ground connection of the earth terminal of the inverter.
- Never remodel it or exchange control boards and components by yourself. It may expose you to an electrical shock or explosion, etc.

- Do not make any voltage-withstanding test with any component inside the inverter. These semiconductor parts are subject to the damage of high voltage.
- Never connect the AC main circuit power supply to the output terminals U,V,W of the inverter.
- The main electric circuit boards of CMOS and IC of the inverter are subject to the effect and damage of static electricity. Don't touch them with your hands.
- Installation, testing and maintenance must be performed by qualified professional personnel.
- The inverter should be discarded as industrial waste. It is forbidden to burn it.




使用说明书

- Do not install the inverter in a space with explosive gas to avoid the risk of explosion. If the inverter is used at or above 100m above sea level, the cooling efficiency will be worse, so please run it by de-rating.
- Do not install any contactor and other components of capacitor or varistor on the output side of the inverter. Otherwise it will cause malfunctions and damages of components of the inverter.
- Do not install any switch component like air circuit breaker or contactor at the output of the inverter. If any of such components must be installed because of the requirements of process and others, it must be ensured that the inverter has no output when the switch acts. In addition, it is forbidden to install any capacitor for improvement of power factor or any varistor against thunder at the output. Otherwise it will cause malfunctions, tripping, protection and damages of components of the inverter. Please remove them as shown in the below diagram.
- It will affect the service life of the inverter if a contact is connected to the front end of input of the inverter to control starts and stops. Generally it is required to control it through FOK or REV terminals. Special attention should be paid to its use in the case of frequent starts and stops.
- Please use an independent power supply for the inverter. Do avoid using the common power supply with an electrical welder and other equipment with strong disturbance. Otherwise it will cause the protection or even damage of the inverter.



2. During the Power-up



Caution

- Do not plug the connectors of the inverter during the power up to avoid any surge into the main control board due to plugging, which might cause damage of the inverter.
- Always have the protective cover in place before the power up to avoid electrical shock injury.

3. During the Operation

- Do not carry the front cover of the inverter directly when handling. It should be handled with the base to prevent the fall-off of the front cover and avoid the dropping of the inverter, which may possibly cause the injuries to people and the damages to the inverter.
- Mount the inverter on a metal or other non-combustible material to avoid the risk of fire.
- Install the inverter in a safe location, avoiding high temperature, direct sunlight, humid air or water.
- Keep the inverter from the reach of children or persons not concerned.
- The inverter can only be used at the places accredited by our company. Any unauthorized working environment may have the risks of fire, gas explosion, electric shock and other incidents.
- Install a heat sink or other cooling device when installing more than one inverter in the same enclosure so that the temperature inside the enclosure kept below 40°C to avoid overheating or the risk of fire.
- Be sure to turn off the power supply before disassembling or assembling the operation key panel and fixing the front cover to avoid damage causing faults or non-display of the operator.



Danger

- Never remove the front cover of the inverter while the inverter is powered up to avoid any injury of electric shock.
- Do not come close to the machine when the fault restart function is used to avoid anything unexpected. The motor may automatically restart after it stops.
- The function of STOP Switch is only valid after setting, which is different with the use of emergent stop switch. Please pay attention to it when using it.

**A Caution**

- Do not touch the heat sink, braking resistor or other heat elements to avoid being scald.
- Be sure that the motor and machine is within the applicable speed ranges before starting operation because the inverter is quite easy to run from lower speed to higher speed.
- Do not check the signals on circuit boards while the inverter is running to avoid danger.
- Be careful when changing the inverter settings. The inverter has been adjusted and set before ex-work. Do not adjust it wantonly. Please make proper adjustments according to the required functions.
- Consider the vibration, noise and the speed limit of the motor bearings and the mechanical devices when the inverter is running at or above the frequency of 50Hz.

III. Standards and Specifications**1. Particular Specifications**

HY900D043B	3Φ 380V 50Hz	90	134	176	90
HY110D43B	3Φ 380V 50Hz	110	160	210	110
HY132D43B	3Φ 380V 50Hz	132	193	253	132
HY160D43B	3Φ 380V 50Hz	160	230	304	160
HY200D43B	3Φ 380V 50Hz	200	290	380	200
HY220D43B	3Φ 380V 50Hz	220	325	426	220
HY250D43B	3Φ 380V 50Hz	250	381	500	250
HY280D43B	3Φ 380V 50Hz	280	427	560	280
HY315D43B	3Φ 380V 50Hz	315	460	605	315

Mini Specifications

Type	Input Voltage	Input Voltage	Power (kW)	Inverter Capacity (kVA)	Output Current (A)	Suitable Motor (kW)
HY-MOD4A	Single Phase 220V 50Hz	Single Phase 220V 50Hz	0.4	1.0	2.5	0.4
HY-M0D75A	Single Phase 220V 50Hz	Single Phase 220V 50Hz	0.75	2.0	5.0	0.75
HY-M1D5A	Single Phase 220V 50Hz	Single Phase 220V 50Hz	1.5	2.8	7.0	1.5
HY-M0D4B	Three Phase 380V 50Hz	Three Phase 380V 50Hz	0.4	1.0	1.5	0.4
HY-M0D75B	Three Phase 380V 50Hz	Three Phase 380V 50Hz	0.75	2.2	2.7	0.75
HY-M1D5B	Three Phase 380V 50Hz	Three Phase 380V 50Hz	1.5	3.2	4.0	1.5

2. General Specifications

Inverter Series	HY-□□
Control Mode	SPWM
Input Power	330~440V for 380V power; 170~250V for 220V power; 50Hz~/60Hz
Display & Status Indicator Lamp	5-Digits Display & Status Indicator Lamp
Communication Control	RS-485
Operation Temperature	-10~40°C
Humidity	0~95% Relative Humidity (without dew)
Vibration	Below 0.5G
Range	0.10~400.00Hz
Accuracy	Digital: 0.01% (-10~40°C), Analog: 0.1% (25±10°C)
Setting Resolution	Digital: 0.01Hz, Analog: 1% of Max. Operating Frequency
Output Resolution	0.01Hz
Operator Setting Method	Press directly □/▽ to set
Analog Setting Method	External Voltage 0~5V, 0~10V, 4~20mA, 0~20mA.
Other Functions	Frequency lower limit, starting frequency, stopping frequency, three skip frequencies can be respectively set.



- It is better not to store the inverter for long time. Longtime storage of the inverter will lead to the deterioration of electrolytic capacity. If it needs to be stored for a long time, make sure to power it up one time within a year and the power-up time should be at least above five hours. When powered up, the voltage must be increased slowly with a voltage regulator to the rated voltage value.



2. Installation Site and Environment

The inverter should be installed at the following location:

- Ambient temperature -5°C to 40°C with good ventilation.
 - No water drop and low moisture.
 - Free from direct sunshine, high temperature and heavy dust fall.
 - Free from corrosive gas or liquid.
 - Less dust, oil, gas and metallic particles.
 - Free from vibration and easy for service and inspection.
 - Free from the interference of electromagnetic noise.
- Attention: The ambient conditions of the inverter will affect its service life.

3. Installation and Direction

- There must be enough space left around the inverter for easy maintenance and cooling. See Diagram.
- The inverter must be installed vertically with smooth ventilation for effective cooling.
- If there is any instability when installing the inverter, please put a flat board under the inverter bottom base and install it again. If the inverter is installed on a loose surface, stress may cause damage of parts in the main circuit boards to damage the inverter.
- The inverter should be installed on non-combustible materials, such as iron plate.
- If several inverters are installed, upper and lower together in one cabinet, please add heat dissipation plates and leave enough space between the inverters. See Diagram.



Ramp Control	Selectable 4-speed steps ramp-up and down time (0.1~6500s).
V/F Curve	Set V/F curve at 111
Torque Control	Torque increase is settable by max. 10.0%. The starting torque can reach 150% at 1.0Hz.
Multi-Inputs	6 multi-function input terminals for 8-speed steps control, program operation, switching of 4-speed Ramp, IP, DOPN function, counter, external emergency stop and other functions.
Multi-Outputs	5 multi-function output terminals for displaying of running, zero speed, counter, external abnormality, program operation and other information and warnings.
Other Functions	ANR (auto voltage regulation), Deceleration stop or free-stop, DC brake, auto reset and restart, frequency track, PLC control, traverse function, drawing control, auto energy-savings, carrier adjustable by max. 20KHz, etc.
Over load Protection	Electronic relay protection motor drive (for constant torque 150%/1 min. For the kinds of fan 120%/1min.)
FUSE Protection	FUSE broken, Motor stops.
Over-voltage	DC Voltage >400V for 220V class DC Voltage >800V for 380V class
Low Voltage	DC Voltage <200V for 220V class DC Voltage <400V for 380V class
Instant Stop and Restart	Restarted by frequency track after instantaneous stop.
Stall Prevention	Anti-start during Acc/Dec run
Output End Shorts	Electronic circuit protecting
Other Functions	Fin over-heat protection, restriction of reverse running, direct start after power on, fault reset, parameter lock PID, one-dimension more, etc.

IV. Storage and Installation

1. Storage

The inverter must be kept in its original package box before installation. Pay attention to the following when keeping it in storage:

- It must be stored in a dry place without rubbish or dust.
- The suitable temperature for storage is between -20°C and +65°C.
- The relative humidity requires 0~95% without condensation.
- There is no corrosive gas or liquid in the storage ambience.
- It's better to lay the inverter on a rack and keep it in a proper package.



使用说明书

HY11D043B~HY30D043B

V. Wiring

1. Main Circuit Schematic Diagram



Power supply: Verify that the inverter's rated voltage coincides with AC power supply voltage to avoid damage of the inverter.

No fuse breaker: Refer to the related list.

Ground fault circuit interrupter: Use one of anti-highharmonic.

Electromagnetic contactor:

Note: Do not use the electromagnetic contactor as the on/off button of power supply for the inverter.

AC reactor: It is recommended to install an AC reactor for power factor improvement if the input capacity is more than 1000KVA.

Inverter:


- Be sure to make correct connections of the main circuit wires and control signal wires of the inverter.
- Be sure to make correct setting of parameters for the inverter.




2. Description of Terminal Block

1) Arrangement of Main circuit Terminals

HY04D043B~HY05D043B HY04D023B



HY04D043B~HY05D043B HY04D023B



2) Mini Specification of Control Circuit Terminals

The inverter crown's RST connection turning on power source, the baseUVW connection outputs the motor. The 220V power source may turn on RST willfully two phase.

UPF	DRV	DCM	SPL	SPM	SPH	RST	REV	FOR	ACM	V0	10V
FA	FC	FB		KA	KB				ACM	AI	RS+

Notes: Uses the kneading boardpotentiometer, please J1 post 2-3 foot shortcircuit , like chart:



Uses the external connectionpotentiometer or the external power supply, like chart:



3) Function Description of Main circuit Terminals

Symbol	Function Description
R, S, T	Input terminal of AC line power. (220V class, for both single/three phase)
U, V, W	Output terminal of the inverter
P, Pr	Connector for braking resistor.
PIP	Connector for DC reactor (When using a DC reactor the jumper shall be removed.)
E	Ground terminal: the third method of grounding for 220V and special grounding for 380V of Electrical Engineering Regulations.




4) Function Description of Control Circuit Terminals

3. Basic Connection Diagram

The wiring of the inverter is divided into two parts, main circuit terminal connections and control circuit terminal connections. The user can see the main circuit terminals, and the control circuit terminals after removing the cover of enclosure. The terminals must be connected correctly as the following wiring circuit diagrams.

Symbol	Function Description	Factory setting
FOR	Multi-Input 1	Forward run
REV	Multi-Input 2	Reverse run
RST	Multi-Input 3	Reset
SPH	Multi-Input 4	High speed
SPM	Multi-Input 5	Middle Speed
SPL	Multi-Input 6	Low Speed
DGM (COM)	Common Terminal of Digital and Control Signals, +12v Power, (EV, IPV, P24) Ground	
+10	Power Supply for Speed Setting	+10V
VI	Analog Voltage Frequency Reference Input	0~10V corresponding to the highest frequency
AI	Analog Current Frequency Reference Input	4~20mA corresponding to the highest frequency
ACM (GND)	Common Terminal of Analog and Control Signals	
DRV	Multi-Output 1 (optical couple output)	DC24V / 100mA
UPF	Multi-Output 2 (optical couple output)	
FA(MB) FB(MA) FC(MA)	Multi-Output 3 (N/O or N/C)	3A/250V
KA(EKA) KB(EKB)	Multi-Output 4 (N/O)	3A/250V
V0	Output terminals of digital frequency	0~10V
RS+ RS-	RS485 Communication port	



Note: The above wiring diagram explained that only supplies the reference, take the actual product as the standard, if has the change not to inform.

4. Precautions on Wiring

1) For the main circuit wiring:

- While wiring the sizes and specifications of wires should be selected and the wiring should be executed according to the electrical engineering regulations to ensure the safety.
- It is better to use shielded wire or wire and conduit for power cord and ground the shielded layer or two ends of wire conduit.
- Be sure to install a Non Fuse Breaker (NFB) between the power supply and the input terminals (R.S.T). (if using ground fault circuit interrupter, please choose one corresponding to high frequency)
- Never connect AC power to the output terminal (U,V,W) of the inverter
- Output wires mustn't be in touch of the metal part of the inverter enclosure, or it will result in earth short-circuit.
- Phase-shifting capacitors, LC, RC noise filters, etc, can never be connected to the output terminals of the inverter.
- The main circuit wires must be enough faraway from other control equipments.
- When the wiring between the inverter and the motor exceeds 15 meters for 220V class or 30 meters for 380V class, much higher dV/dt will be produced inside the coil of the motor, which will cause the destruction to the interlayer or insulation of the motor. Please use a dedicated AC motor for the inverter or add a reactor at the inverter.





VI. Instruction of the Digital Operator

1. Description of the Digital Operator

- Please lower the carrier frequency when there is a longer distance between the inverter and the motor. Because the higher the carrier frequency is the bigger the leakage current of high-order harmonics in the cables will be. The leakage current will have unfavorable effect on the inverter and other equipment.

2) For control circuit wiring (signal line)

- The signal line should be separately laid in a different conduit with the main circuit wire to avoid any possible interference.
 - Please use the shielded cable with the size of 0.52mm² for signal lines.
 - Use the control terminals on the control panel correctly according to your needs.
- #### 3) Grounding
- Grounding terminal E. Be sure to make correct grounding
 - 220V class: The third grounding method (Grounding resistance should be 100 ohm or lower.)
 - 380V class: The special third grounding method (Grounding resistance should be 10 ohm or lower.)
 - Choose grounding wires according to the basic length and size of the technical requirements of the electric equipment.
 - Do not share grounding wire with other large power equipment such as electric welder, power machine, etc. The grounding wire should be kept away from the power supply wires for large equipment.
 - The grounding method for several inverters together should be done as the first and second diagrams below. Avoid the third loop.
 - The grounding wire must be as shorter as possible.



NOTE: The LED main display zone demonstrates by 5 digits, the second main display zone demonstrates the 5th digit.
Example: 12345, 1234 digit first main displayzone, digit 5 in the second main displayzone



Description of Indicator Lamp Status

1) Description of Indicator Lamp Status

Indicator Lamp	Status	Description
FOR	on	The motor is in forward rotation.
REV	on	The motor is in reverse rotation.
HZ	on	Displaying set frequency or output frequency.
A	on	Displaying output current.
ROTT	on	Displaying rated motor revolution
HZ A	on	Displaying DC voltage.
A ROTT	on	Displaying AC voltage.
HZ ROTT	on	Displaying counting value.
HZ A ROTT	on	Displaying internal temperature of the inverter.

2. Description of Operation Examples

Procedures	Display	Indicator Lamp	Explanation
Power up. Operation of power ↓	Dsp2.0 Flash →Nr2.00 →00.00	FOR HZ ↙	Self detect when power-up, display version no. (Flashing) and finally set frequency.
PRGM ↓	Pd000	FOR HZ ↙	Enter programming Display the function of Pd000
ENYER (SET) ↓	000.0X	FOR HZ ↙	Display the contents of Pd003
▲ ↓ ← END →50.00 Pd003 → 050.0X PRGM ↓ RUN	X0.00 END →50.00 Pd003 → 050.0X PRGM ↓ 50.00	FOR HZ ↙ FOR HZ ↙ FOR HZ ↙	Change the content of Pd003 Confirm changed value. Display END 50.00 Pd004 Back from programming Display running and operating frequency Monitor screen switching, display
DISP SHIFT ↓ PRGM	50.00 →50.00 PRGM	FOR HZ ↙ FOR HZ ↙	Monitor screen switching, display output current Monitor screen switching, display output current



Procedures	Display	Indicator Lamp	Explanation
↓ DISP	01440 FOR A ▢	Monitor screen switching, display revolution	Self detect when power up, display version no. and finally set frequency
↓ PROG	└ 50.00 FOR ROTT ▢	Switch back to main screen, display set frequency	Switch to adjustable frequency on the panel!
↓ JOG	└ 50.00 FOR HZ ▢	Switch of For. Rev. rotation, display the status of Rev.rotation	Change set frequency, i.e. The value of Pd003
↓ ▲	050.00 FOR HZ ▢	Switch to adjustable frequency	Confirm changed value
↓ → ▲	050.00 FOR HZ ▢	Adjust set frequency, i.e. the value of Pd003	Run at 50Hz
↓ ENTER	030.00 FOR HZ ▢	Confirm changed value, write to Pd003 as value	Stop
↓ STOP	└ 50.00 FOR HZ ▢	Stop	Stop

Note: ▢ means indicator lamps is on; ↗ means indicator lamps flash;

Note:
 ↗ means flashing, ▢ means bright.
 ① ↗ means connected wires? Pay special attention to the terminal of U.V.W; Make sure the power supply wires are connected to R.S.T, not U.V.W.
 ② For monitoring AC, DC, T and other items they can be only switched and displayed after the parameter setting.
 ③ When it is powered up again after a power breakdown the inverter will display the screen previous to the power breakdown after its self detection.

VII. Commissioning

1. Important Checks before the Commissioning

If there is any wrong connected wires? Pay special attention to the terminal of U.V.W; Make sure the power supply wires are connected to R.S.T, not U.V.W.
 If there is any metal powder or wires left on the base plate of the inverter or the terminal block, which may cause short circuit.
 If screws are tightly locked and if the connecting parts are loose.
 If there is any short circuit or earth fault at outputs.

2. Commissioning Methods

The procedure of the operator is factory set up for the control mode of HY series. The commissioning can be carried out through the digital operator. Generally, the commissioning can be conducted at 5.00 Hz.



VIII. Function List

Parameters Function List 1

Category	Code	Function	Set Range & Function Explanation	Factory Setting
PD000	Parameter Lock	0: Invalid 1: Valid	0	
PD001	Source of Run Commands	0: Operator 1: External terminal 0 2: Communication port	0	
Pd002	Source of Operating Frequency	0: Operator 1: External terminal 0 2: Communication port	0	
PD003	Main Frequency	0.00~400.00 Hz	*	
PD004	Base Frequency	0.01~400.00 Hz	50.00	
PD005	Max Operating Frequency	50.00~400.00 Hz	50.00	
PD006	Intermediate Frequency	0.01~400.00 Hz	2.50/3.0	
PD007	Min. Frequency	0.01~20.00 Hz	0.50	
PD008	Max. Voltage	0.1V---*	220/380	
PD009	Intermediate Voltage	0.1V---*	*	
Pd010	Min. Voltage	0.1~50.0V	*	
PD011	Frequency Lower Limit	0.00~400.00 Hz	0	
PD012	Reserved			
PD013	Parameter Reset	00~10: Restore the factory setting. No other function.	00	
PD014	Accel. Time 1	0.1~6500.0S	*	
PD015	Decel. Time 1	0.1~6500.0S	*	
PD016	Accel. Time 2	0.1~6500.0S	*	
PD017	Decel. Time 2	0.1~6500.0S	*	
PD018	Accel. Time 3	0.1~6500.0S	*	
PD019	Decel. Time 3	0.1~6500.0S	*	
PD020	Accel. Time 4	0.1~6500.0S	*	
PD021	Decel. Time 4	0.1~6500.0S	*	
PD022	Reserved			
PD023	Rev. Rotation Select	0: Rev Run forbidden; 1: Rev Run Enabled	1	
PD024	STOP key select	0: STOP Invalid 1: STOP Valid	1	
PD025	Starting Mode	0: Start from Starting Frequency 1: Frequency track start	0	
PD026	Stopping Mode	0: Decelerating stop 1: Coasting stop	0	
PD027	Starting Frequency	0.1~10.0 Hz	0.5	
PD028	Stopping Frequency	0.1~10.0 Hz	0.5	

Category	Code	Function	Set Range & Function Explanation	Factory Setting
PD029	Braking time at start	0~25.0		0.0
PD030	Braking time at stop	0~25.0		0.0
PD031	DC Braking level	0.0~20.0%		2.0
PD032	Frequency track time	0.1~20.0S		5.0
PD033	Current level for frequency track	0~200.0S		150.0
PD034	Voltage rise time during frequency track	0.1~10S		0.5
PD035~PD040	Reserved			
Pd041	Carrier frequency	0~15	*	
PD042	Jogging Frequency	0.00~400.00Hz		5.00
PD043	S-Curve Time	0~6500S		0

Parameters Function List 2

Category	Code	Function	Set Range & Function Explanation	Factory Setting
Pd044	F0R (D1)		0: Invalid; 1: Run; 2: For rotation; 02: Rev. rotation; 4: Stop; 5: File/REV.; 6: Jog; 7: Jog For rotation; 03: Jog Rev. rotation; 9: timer1; 10: timer2; 11: Reserved; 12: Overheat of heat sink or motor; 13: Emergency stop; 14: Reset; 15: 16: Reserved; 17: Ramp select; 18: Ramp select2; 19: Multi-speed; 20: Multi-speed; 21: Multi-speed 3; 22: High speed; 23: Middle speed; 24: Low speed; 25: PID Start; 26: Counter; 27: UP function Counter; 28: DOWN function Counter; 29: Reserved; 30: Drawing; 31: Counter; 32: Counter reset	
Pd045	REV (D2)			
Pd046	RST (D3)			
Terminals of Input \Output				
PD047	SPH (D4)			
PD048	SPL (D5)			
Pd049	SPM (D6)			

Pd050	Y1 Output	0: Invalid; 1: Run; 2: Zero Speed; 3: Fault indication; 4: Braking indication; 5: Set Frequency reach; 6: In Accel.; 7: In Decel.; 8: Arbitrary Frequency 1 reach; 9: Arbitrary Frequency 2	01
Pd051	Y2 Output		05
Pd052	Terminals of FA, FB, FC		03



Parameters Function List 3

Input and Output Terminals					
Pd053	Terminals of KA, KB	10: Motor Over-load alarm; 11: Over-torque alarm; 12: Inverter/over load alarm; 13: Counter/reach 14~16: Reserved; 17: Low voltage alarm; 18: Single stage end indication; 19: Process end indication; 20~26: Reserved; 27: Drawing reach; 28: PID lower limit alarm; 29: PID upper limit alarm; 30: Reserved; 31: Braking resistor act; 32: Fan act.			
PD054	V0 output	Output of digital frequency 0 signals 0~7			
PD055	V0 Analog output Gain	0.0~100.0%	100		
PD056	Skip Frequency 1	0.00~400.00 Hz	0.00		
PD057	Skip Frequency 2	0.00~400.00	0.00		
PD058	Skip Frequency 3	0.00~400.00	0.00		
PD059	Skip Frequency Range	0.10~10.00	0.50		
PD060	Uniform Frequency 1	0.00~400.00 Hz	0.00		
PD061	Uniform Frequency 2	0.00~400.00 Hz	0.00		
PD062	Uniform Frequency Range	0.10~10.00 Hz	0.50		
PD063	Timer 1 time	0~10.0	0.1		
PD064	Timer 2 time	0~100	1		
PD065	Counting value set	0~65500	00		
PD066	Intermediate Counter	0~65500	0		
PD067~ PD069	Reserved				

Category	Code	Function	Set Range & Function Explanation	Factory Setting
			0.0~10V 1.0~5V 2.0~10A 3.4~20mA 4.0~10A, stacked 4~20mA External pulse of input	0
	Pd070	Analog Input		
	Pd071	Analog Filtering Constant	0~50	20
	Pd072	Lower Analog Frequency	0.00~400.00 Hz	50.00
	Pd073	Higher Analog Frequency	0.00~400.00 Hz	0
	Pd074	Bias Direction at Higher Frequency	0: Positive direction 1: Negative direction	0
	Pd075	Bias Direction at Lower Frequency	0: Positive direction 1: Negative direction	0
	Pd076	Analog Negative Bias Reverse	0: Not allowable. 1: Allowable.	0
	Pd077	Up/Down Function	0: Not memorized 1: Memorized	0
	Pd078	Up/Down Speed	0: 0.01Hz 1: 0.1Hz	0
	Pd079	Reserved		
Category	Code	Function	Set Range & Function Explanation	Factory Setting
Mulit-speeds Operation	Pd080	PLC Operation	0: Normal run; 1: Internal control 10-speed; 2: External control 4-speed; 3: External control 3-speed 4: Drawing 5: Disturbance;	0
	Pd081	Internal Control Multi-speeds Operation	0: Stop after running for one cycle; 1: Cycling run; 2: Auto stop after running for one cycle 3: Auto Run and Operation; 4: Stop (STP for intervention)	0



Parameters Function List 4

Category	Code	Function	Set Range & Function Explanation	Factory Setting
PLC Before 8 speeds Running Direction	PD082	0~255 (0: For 1: Rev)	0	0
PLC After 8 speeds Running Direction	PD083	0~255 (0: For 1: Rev)	0	1
Before 8 speeds PLC Ramp Time	PD084	0~65535	0	150
After 8 speeds PLC Ramp Time	PD085	0~65535	0	0
Frequency 2	PD086	0.00~400.00 Hz	15.00	5
Frequency 3	PD087	0.00~400.00 Hz	20.00	150
Frequency 4	PD088	0.00~400.00 Hz	25.00	0
Frequency 5	PD089	0.00~400.00 Hz	30.00	0
Frequency 6	PD090	0.00~400.00 Hz	35.00	1.0
Frequency 7	PD091	0.00~400.00 Hz	40.00	0
Frequency 8	PD092	0.00~400.00 Hz	0.50	0
Frequency 9	PD093	0.00~400.00 Hz	10.00	0
Frequency 10	PD094	0.00~400.00 Hz	15.00	0
Frequency 11	PD095	0.00~400.00 Hz	20.00	0
Frequency 12	PD096	0.00~400.00 Hz	25.00	0
Frequency 13	PD097	0.00~400.00 Hz	30.00	0
Frequency 14	PD098	0.00~400.00 Hz	35.00	60
Frequency 15	PD099	0.00~400.00 Hz	40.00	5 s
Frequency 16	PD100	0.00~400.00 Hz	45.00	
Multi-speeds Operation				
Timer 1	PD101	0.0~6500.0S	10.0	60s
Timer 2	PD102	0.0~6500.0S	10.0	60s
Timer 3	PD103	0.0~6500.0S	0.0	95s
Timer 4	PD104	0.0~6500.0S	0.0	30s
Timer 5	PD105	0.0~6500.0S	0.0	80%
Timer 6	PD106	0.0~6500.0S	0.0	20.00
Timer 7	PD107	0.0~6500.0S	0.0	20s
Timer 8	PD108	0.0~6500.0S	0.0	
Timer 9*	PD109	0.0~6500.0S	0.0	
Timer 10	PD110	0.0~6500.0S	0.0	
Timer 11	PD111	0.0~6500.0S	0.0	
Timer 12	PD112	0.0~6500.0S	0.0	
Timer 13	PD113	0.0~6500.0S	0.0	
Timer 14	PD114	0.0~6500.0S	0.0	*
Timer 15	PD115	0.0~6500.0S	0.0	*
Timer 16	PD116	0.0~6500.0S	0.0	04 1440
Water Supply with Constant Pressure				
High Speed Running Time	PD133	1~250s		
Low Speed Running Time	PD134	1~250s		
Stopping Voltage Level	PD135	1~150%		
Lasting Time of Stopping Voltage Level	PD136	1~250s		
Wakeup Level	PD137	1~50%		
Sleep Frequency	PD138	0.00~400.0		
Sleep Frequency	PD139	1~250s		
Lasting Time of Sleep Frequency	PD140			
Motor Function Parameters				
Rated Motor Voltage	PD141	Set according to Motor nameplate	*	
Rated Motor Current	PD142	Set according to Motor nameplate	*	
Motor pole number.	PD143	0.210	04	
Rated Motor Revolution	PD144	0.09999	1440	



使用说明书

Monitor Function		Display Items		Set according to the model		Set according to the model	
PD145	Auto Torque Compensation	2.0~10.0	2.0	PD170 PD171 PD172	Display Items Open Fault Clear	0~5 0~15	0 0
PD146	Motor no-load current	0100	40	PD173	Voltage Rating of Inverter	00 10(01 for Fault Clear)	*
PD147	Motor slip compensation	0.0~100	0.0	PD174	Rated Current of Inverter	Set according to the model	*
PD148~ PD149	Reserved			PD175 PD176	Inverter Model Inverter Frequency Standard	0: 50Hz 1: 60Hz	0
PD150	Auto Voltage Regulation	0~1	+	PD177	Fault Record 1		*
PD151	Auto Energy Saving	0~20	0	PD178	Fault Record 2	Note:	—
PD152	Fault Restart Time	0.2~25	1	PD179	Fault Record 3	Means no fault record.	—
PD153	Restart after Instantaneous Stop	0: Invalid 1: Frequency track	0	PD180	Fault Record 4	—	—
PD154	Allowable Power-Breakdown Time	0.1~5.0S	0.5	PD181	Software Version	—	—
PD155	Number of Abnormal Restart	0~10	00	PD182	Manufacture Date	Year: Month: Week:	*

Parameters Function List 5

Category	Code	Function	Set Range & Function Explanation	Factory Setting
PID Parameters	PD156	Proportional Constant (P)	0.0~1000.00%	100%
	PD157	Integral Time (I)	0.1~3600.00S	5.0
	PD158	Differential Time (D)	0.01~10.00S	0
	PD159	Target value	0.0~100.0%	0
	PD160	Target value select	{ 1: set by operator 0: set by external terminals (0~0V) 0~100%	0
	PD161	PID upper limit	0~100%	100%
	PD162	PID lower limit	0~100%	0%
Communication Function	PD163	Communication Addresses	0~250	0
	PD164	Communication Baud Rate	0~3	1
	PD165	Communication Data Method	0~5	0
Pd166~Pd169	Reserved			

IV Descriptions of Functions

PD000 Parameter Lock
Set Range: 01 Unit: 1 F

- : Invalid.
- : Valid; i.e. the parameters are locked. Except this parameter other parameters can not be changed. This parameter is set to prevent non-maintenance personnel from setting other parameters by mistake. After the parameters are locked the operating frequency can be changed by pressing Δ or \square .

PD001 Source of Operation Commands

F
Set Range: 02 Unit: 1
Sect by the Observer

Operation commands are given via the digital operators
Set by external terminals.



使用说明书

2: Set by communication ports.
Operation commands are given via communication ports.

PD002 Source of Operating Frequency	Unit: 1	Factory Setting: 0
Set Range: 0~3		

0: Set by the operator. The operating frequency which is given via the digital operator is PD003.
1: Set by external terminals. Operating frequency is controlled by analog signals input via external terminals. The signal type is determined by PD070. For the related parameters refer to PD01-PD07/6.
2: The MODBUS is given. Operating frequency is given via the serial communication.

PD003 Main Frequency	Unit: 0.00~400.00 Hz	Unit: 0.01 Hz	Factory Setting: 0.00	**
Set Range: 0.00~400.00 Hz				


In the digital operator mode, the inverter will run at the set value of PD003. During running, the operating frequency can be changed by pressing ▲ or ▼. During multi-speed running, the main frequency is taken as the frequency of Speed 1.
In the external control multi-speed mode, if PD002 is set to 1, i.e. given by an external terminal, Speed 1 will be given by the analog of the external terminal.
The setting of main frequency is limited by the maximum operating frequency.
The related parameters of PD002, PD080 are adjustable during operation.

PD004 Base Frequency	Unit: 0.01~400.00 Hz	Unit: 0.1 Hz	Factory Setting: 50.00
Set Range: 0.01~400.00 Hz			

This parameter must be set according to the rated frequency of operating voltage on the motor's nameplate. Under normal conditions do not change the serviceable base frequency at will. If it is equipped with a special motor, this value should be set properly according to the characteristics of the motor's parameters. Otherwise it may cause damage to the equipment.

PD005 Max. Operating Frequency	Unit: 0.00~400.00 Hz	Unit: 0.01 Hz	Factory Setting: 50.00
Set Range: 10.00~400.00 Hz			

This parameter is set for the maximum operating frequency of the inverter.
The following are several curves and set values often used for reference. Specific curves must be set according to concrete characteristics of mechanical load.



Code	Pd01	Pd02	Pd03	Pd04	Pd05	Pd06	Pd07	Pd08	Pd09	Pd10	Pd11	Pd12	Pd13	Pd14	Pd15	Pd16
Model	Pd01	Pd02	Pd03	Pd04	Pd05	Pd06	Pd07	Pd08	Pd09	Pd10	Pd11	Pd12	Pd13	Pd14	Pd15	Pd16
HY00D42B	15.0	7.5	5	5	9	003043A	17	8.5	30	30	4					
HY00D52B	14.0	7	8	8	9	003743A	16	8	35	35	4					
HY01D52B	14.0	7	10	10	8	004543A	16	8	40	40	4					
HY02D22B	13.0	6.5	10	10	8	005543A	15	7.5	45	45	3					
HY03D72B	13.0	6.5	15	15	7	007543A	15	7.5	50	50	3					
HY00D54B	22	11	8	8	9	022043A	11	5.5	250	250	2					
HY01D54B	22	11	10	10	8	025043A	11	5.5	250	250	2					



使用说明书

PD010 Min. Voltage Set Range: 0..1~50.0V Unit: 0..1V Factory Setting: *	<p>This parameter is set for the min. starting voltage of V/F curve. The factory setting of min. voltage for 220V class inverters is 8, and the factory setting of min. voltage for 380V class inverters is 13.5. This set value is limited by the voltage at the max. Frequency.</p>
PD011 Frequency Lower Limit Set Range: 0..0~400.00 Unit: 0..01 Hz Factory Setting: **	<p>This is set for preventing workers from false operation to avoid over-heat or some other mechanical faults, which might be caused due to too low operating frequency. The setting of Frequency Lower Limit must be less than the set value of Frequency Upper Limit.</p>
PD012 Reserved	
PD013 Parameter Reset	<p>When the value for a parameter is set improper or is abnormal for some reasons this parameter can be set to 0 to restore it to the factory setting and then reset. After the parameters are locked (in case of PD000=1) the parameters can't be reset. They can only be reset after unlock. For related parameters refer to Pd000.</p>
PD014 Accel. Time 1 Set Range: 0..16~500.0S Unit: 0..1S Factory Setting: *	
PD015 Decel. Time 1 Set Range: 0..16~500.0S Unit: 0..1S Factory Setting: *	
PD016 Accel. Time 2 Set Range: 0..16~500.0S Unit: 0..1S Factory Setting: *	
PD017 Decel. Time 2 Set Range: 0..16~500.0S Unit: 0..1S Factory Setting: *	
PD018 Accel. Time 3 Set Range: 0..16~500.0S Unit: 0..1S Factory Setting: *	
PD019 Decel. Time 3 Set Range: 0..16~500.0S Unit: 0..1S Factory Setting: *	
PD020 Accel. Time 4 Set Range: 0..16~500.0S Unit: 0..1S Factory Setting: *	
PD021 Decel. Time 4 Set Range: 0..16~500.0S Unit: 0..1S Factory Setting: *	
PD008 Max. Voltage Set Range: 0..1~*	<p>Note: ①Ramp Time 2=Ramp Time 1 x 2 ②Ramp Time 3=Ramp Time2 x 2 ③Ramp Time = Ramp Time 3 x 2 ④Min. Voltage Value = Intermediate Voltage Value/2 ⑤The intermediate frequency is 2.5 for the system of 50Hz. ⑥The intermediate frequency is 3.0 for the system of 60Hz.</p>
PD009 Intermediate voltage Set Range: 0..15~10..0V Unit: 0..1V Factory Setting: *	<p>This parameter is set for an intermediate voltage value of arbitrary V/F curve. If it is set improperly, it will cause over-current or under-torque of the motor, or even tripping of the inverter. When the intermediate frequency is increased the voltage will increase the output torque and the same time also the output current. When changing this parameter please pay attention to monitoring the output current to avoid the inverter tripping due to over-current. The factory setting of intermediate voltage for 220V class inverters is 27.5, while the factory setting of intermediate voltage of 380V class inverters is 15, while the factory setting is increasing to a certain value at intermediate frequency the torque compensation will be set. When adjusting this parameter the output current of the inverter should be increased from low to high slowly according to the load of machines until it meets the starting requirement. Do not quick to increase it by large amplitude. Otherwise it might cause the tripping of the inverter or the damage of the machines.</p>




使用说明书

- 0: Start from the starting frequency.
When PD029 is set to 0, i.e. DC braking is invalid at start, it starts running from the starting frequency. When PD029 is set to any non-zero value, i.e. DC braking is valid at start, it first performs a DC braking at start, and then starts from the starting frequency.

For the Related parameters refer to PD027, PD029 and PD031.

- 1: Start by frequency track
This setting can be used for the restarting of large inertia load. When restarting, the inverter will reach the former frequency from the set frequency downward. In case of large inertia equipment, when restarting, it can implement the running command and track the former frequency right away without waiting for the complete stop of the equipment to save time.

Note: When the inverter is restarted by frequency track, it will start tracking the frequency from its set frequency downward, and search it at the highest speed. When restarting, the current becomes higher, and over-current or stall may occur. So attention must be paid to the adjustment of current level of frequency track. Generally, PD035 is adjusted around 100. The concrete value can be set according to the characteristics of mechanical load.




Note:

The versions previous to Vr2.0 took 50Hz as the base of ramp time. HY-A Series inverter have altogether 4 Ramp Times. For Ramp Time 2,3,4, the user can select the different ramp up or downtime through the external terminals or switching of ramp time according to the actual needs.

In the internal control multi-speed operation, different ramp time can be selected through easy PLC.

Generally the default of the inverter is Ramp Time 1, which is factory set depending on the model. Ramp Time 4 is for the jogging ramp time. For the factory setting of parameters refer to the table in Pd007. The related parameters: PD044~PD049 and P084~PD085



PD023 Rev Rotation Select	Unit: 1
Set Range: 0~1	Factory Setting: 1

PD026 Stopping Mode	Unit: 1
Set Range: 0~1	Factory Setting: \$

- 0: Rev Rotation disable
1: Rev Rotation Enable
This function is suitable for the motor, which is not allowed to rotate reversely, to prevent workers from false operation. When the reverse rotation is disabled, the motor can only rotate forward, not reverse.

PD024 STOP key	Unit: 1
Set Range: 0~1	Factory Setting: 1

- 0: STOP invalid
1: STOP valid
This parameter set is only valid when PD001 is set to 0 or 2.
When the control mode is set for external terminals or communication control, STOP key on the panel can be chosen to be valid or invalid. When choosing its valid, STOP key can stop the inverter in running. When it needs to restart, the former running signal must be released before restarting the inverter.

PD025 Starting Mode	Unit: 1
Set Range: 0~1	Factory Setting: 0

Two starting modes are available for the needs of different equipment.

PD027 Starting Frequency	Unit: 0.1~10.0 Hz
Set Range: 0~1	Factory Setting: \$

Factory Setting: 0



使用说明书


Starting frequency is the initial frequency when the inverter is started. If the starting frequency is set to 5.0 Hz, the inverter will run between 5.0 Hz and the maximum operating frequency after its start at 5.0 Hz.

For the related parameters refer to PD025, PD031 and PD029.

P0028 Stopping Frequency
Set Range: 0.1-10.0 Hz Unit: 0.1Hz Factory

When stopping the inverter will decrease its frequency to the stopping frequency and then stop running or start DC braking to stop.

If PD030 is set to 0, DC braking is invalid at stop and the inverter will stop running. If PD030 is set to 1, DC braking is valid at stop and the inverter will stop running. If PD030 is set for valid, the inverter will stop at DC braking when the inverter reduce to PD028. For the related parameter refer to PD026, PD031 and PD030.



This parameter is set for DC Braking at start and the lasting time of DCBrakingcurrent tothemotor. If its setto zero it means DC braking is invalid.

If DC Braking at start is normally used in the application, in which the load is movable when the motor is at stop, such as windmill. Because of the load existing before the inverter drives, the motor is often in coasting with uncertain rotation direction. So the DC braking can be executed before starting the motor to prevent from tripping.

This setting is valid only when P0025 is set to 0 or for the related parameters refer to P0025, P0029

P0030	DC Braking Time at stop Set Range: 0..25.0	Unit: 0..1S	Fact
-------	---	-------------	------

Note: When this parameter is set to any non-zero value it starts DC brake at stop and sends the DC braking time to the motor. DC braking at stop is often used for a high-level stop or positioning control. When this parameter is set to zero it closes DC braking at stop. This setting is valid when PD026 is set to 0. For further details refer to PD026, PD028 and PD029.

This setting is valid when PD026 is set to 0. For the related parameters refer to PD026, PD028 and PD031.

PD031 DC Braking Voltage Level
Set Range: 0~20.0% Unit: 0.1% Factory Setting:

This parameter is set for the DC braking voltage to the motor at start and stop. It can be adjusted for different braking voltage. When adjusting the parameter must be increased slowly from lower value to high value until the sufficient braking torque is achieved.

The voltage at maximum frequency is 100% voltage.

PD032 Frequency Track Time Unit. 0.1S
Set Range: 0.12~0.0S Factory Setting

This parameter is set as frequency track time when the inverter is started by frequency track after an external abnormality or temporary power breakdown. For starting or stopping of some large inertia load, if restarting a machine after its complete stop, it will waste much time because of its large inertia load. But if the frequency track is started, it is not necessary to wait for the machine to come to a full stop for restart. The inverter will trace the frequency from high to low with the set frequency. After

PD033 Current Level for Frequency Track
Set Range: 0-200% Unit: 1%
Factory Setting: 100%

When the inverter is tracing the frequency this set value is taken as the level for output current. When the output current is higher than this level the inverter will decrease the frequency to restore the current below the level and then it will execute the frequency track again.

When the inverter is started by frequencytrack in the track process, the voltage will drop when the voltage unspeed-increase, the current will higher, the track process will faster. When the voltage unspeed-increase, the current will higher, the track process will faster. When the voltage unspeed-increase, the current will higher, the track process will faster. When the voltage unspeed-increase, the current will higher, the track process will faster.

speed decrease , current will lower, the track process will slower. In generally setting way is the low power machine establishes small, the high power machine establishes big.

Pd035 Pd040 RESERVED Pd041 Carrier Frequency (Note: 015 corresponds to 020K Hz)
Set Range: 015 Init: 1 Factor Se.

The carrier frequency has some relation with the electromagnetic noise of the motor, and mean while the level of the carrier frequency has certain relation with the heating capacity of the inverter and the interference to the environment. See the following table.

Carrier Frequency	Electromagnetic Noise	Heating Capacity	Interference to the Environment
Low ↓	High ↓	Small ↓	Little ↓
	Low	Large	Great



使用说明书

Carrier Frequency Corresponding Table

Set Value	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Carrier Frequency KHz	0.1	1	1.5	2	3	4	5	7	8	9	10	11	13	15	17	20

As shown in the table above, the higher the carrier is, the lower the electromagnetic noise of the motor will be, but the stronger its interference to other systems will be and the greater the heating capacity of the inverter will have. Under higher ambient temperature and heavier load of the motor the carrier frequency should be decreased properly to improve the heat characteristics of the inverter.

The factory setting of carrier frequency is depending on the model.


PD042 Logging Frequency**
Set Range: 0..00~400.00 Unit: 0.01 Factory Setting: 5.00

The parameter set can realize the logging function when the inverter is tested. The logging operation can be only achieved through the external terminals, which can be set by multi-input terminals. Logging frequency is limited by the frequency upper/lower limits. Whilst the jogging function is implemented, other running commands are invalid. The ramp-up time of jogging frequency is set by Ramp-up Time 4. When the jog button is released the inverter will stop output immediately. In case of jogging function please set the corresponding multi-input terminals to 0 or 08.

This function is only valid at stop. It is invalid at running. For the related parameters refer to PD044-PD049.

PD043 S-Curve Time
Set Range: 0..65500S Unit: 1 Factory Setting: 1

This parameter can be set for noimpact slow start or slow stop of the inverter when starting or stopping. When starting S-curve the inverter will make accelerating or decelerating curve of different speed rates according to Ramp Time.



When PD043 is set as 0, S-curve is invalid, i.e. it will accelerate or decelerate in linear. Without consideration of stall the actual accel./decel. time = $(PD044+PD043)/2$. The parameter is only valid when PD044 is less than

PD044	FOR (D1) Function	Factory Setting:
PD045	REV (D2) Function	02
PD046	RST (D3) Function	03
PD047	SPH (D4) Function	14
PD048	SPM (D5) Function	22
PD049	SPL (C6) Function	24
	Set Range: 00~32	Unit: No


- 01: RUN Running. It can be combined with other terminal to compose multiple control modes.
- 02: FOR Forward Rotation
- 03: REV Reverse Rotation
- 04: STOP Stopping
- 05: FOR/REV Switching of FOR/REV rotation
- 06: JOG Logging
- 07: Jog FOR Rotation
- 08: Jog REV Rotation
- 09: External Control Timer 1 Start: When the contact is closed, the timer will start and begin to count time. When the timer reaches these point the corresponding multi-outputs will act.
- 10: External Control Timer 2 Start: Over-head of heat sink or motor: This contact can be used to detect over-heat of the heat sink or motor to protect themotor and inverter.
- 11: Emergency Stop: Emergency stop. It can receive external emergency stop command or other fault signals.
- 12: Reset: This terminal can be used for reset after a fault is removed.
- 13: Reserved.
- 14: Reserved.
- 15~16: Reserved.
- 17: Ramp Time1: This terminal can be used to select the ramp time of the inverter.
- 18: Ramp Time2: 4 kinds of ramp time are available for choice.
- 19: Multi-speed 1: 8-speed setting can be composed through Multi-speed 1, 2, 3.
- 20: Multi-speed 2
- 21: Multi-speed 3
- 22: High, middle and low speed can compose three kinds of operation mode
- 23: Middle speed with different frequencies. In the three terminals the high-end signal has priority. Low, Middle and High Speed are determined respectively by Frequency 2, 3, 4.
- 24: Low speed
- 25: PID Valid: When this contact is closed, PID function starts. PID Function start is only valid during operation.
- 26: PLC Reset Suspend: This contact can be used to achieve the function of AutoPLC clear suspend.
- 27: UP Function: When the switch of this terminal acts the frequency setting of the inverter will be increased or decreased by one unit. Whenthe switch of this terminal is held the frequency will increase or decrease rapidly to a point and then increase or decrease.



- 28: Down Function at even speed. When the power is up again after the powerbreakdown the changed frequency will not be memorized.
- 29: Drawing Start When this contact is triggered the drawing actionstarts.
- 31: Pulse Counter When this terminal is set for the counter it can receive thepulse signal of $\leq 250\text{Hz}$ and counts.
- 32: Counter Reset When this contact actit will clear thepresent counting values displayed,restore 000 and restart counting.

D4	D5	Result
OFF	OFF	Ramp Time 1
ON	OFF	Ramp Time 2
OFF	ON	Ramp Time 3
ON	ON	Ramp Time 4

4. Function description of High, Middle and low speed terminals:



Explanation:

1. Three multi-function terminals can be used for the connection of FOR/REV system for the realization of switching of FOR/REV rotation, which is extensively applied in the cases of photoelectric switches.

① Select the multi-function terminals of D1, D2 and D3

② Parameter setting:

PD001=1 for external control PD044=02 for FOR rotation


PD045=03 for REV Rotation PD046=04 for Stop

③ Action Description:

When triggering D1, the inverter will rotateforward (start);

When triggering D2, the inverter will rotatereverse;

When pressing STOP, the inverter will stop.



2. RUN, DGM, F/R can be used for Start, Stop and switching of FOR/REV:

① Select the terminals of D1 and D2


② Parameter setting:

PD001=1 for external control

PD044=01 for R/L/N function

PD045=05 for switching of F/R

When K2 is opened it rotates forward, while K2 is closed it rotates reverse.



3. Description of Ramp Time 1 and 2:

- ① This function is only valid when PD080 is set to 0,2 and 3. Under the disturbance and internalcontrol multi-speed it is invalid.
- ② Any two multi-inputs can be combined for 4 kinds of ramp time for selection.
- ③ The related multi-inputs are set for Ramp Time 1,2. Take the terminals of D4 and D5 as example, when the terminal of D4 PD047 is set to 22 and the terminals of D5 PD048 is set to 23, D4 and D5 are now Ramp Time 1, 2.

Note :

(1) This function is only valid when PD080 is set to 2, i.e. for 4-Speed of external control.

(2) Ramp time is determined by Ramp Select terminal.


(3) When all high, middle and low speeds have signal inputs it will give priority in the sequence of high, middle and low speed.

RUN	D6	D5	D4	Result
ON	OFF	OFF	OFF	Main speed, the frequency runs at the set value of Pd003.
ON	ON	OFF	OFF	Low speed, the frequency runs at the set value of Pd086.
ON	ON/OFF	ON	OFF	Middle speed, the frequency runs at the set value of Pd087.
ON	ON/OFF	ON/OFF	ON	High speed, the frequency runs at the set value of Pd088.



使用说明书

5. Description of UP and DOWN Function:




	UP	DOWN	Result
OFF	OFF	OFF	Frequency increase
ON	ON	ON	Frequency decrease
ON	ON	ON	Not increase or decrease

Note : (1) The function of UP and DOWN is only valid when the operator is selected for the source of the operating frequency, i.e. PD002=0.

- (2) When the UP terminal is closed, the frequency of the inverter will increase.
- (3) When the DOWN terminal is closed, the frequency of the inverter will decrease.
- (4) When both UP and DOWN terminals are closed at the same time, the frequency will neither increase nor decrease. It is regarded as invalid.
- (5) When the frequency reaches the max operating frequency, it will stop increasing.
- (6) When the frequency reaches the min frequency or its lower limit, it will stop decreasing.
- (7) After a power breakdown, the set value of PD003 will be memorized instead of the frequency.
- (8) When using the function of UP and DOWN, the keys of \triangle of the panel are valid. After changing the values, it needs to press SET(ENTER) key for confirmation and then the inverter can implement the action. Meanwhile the value will write to PD003, which will be memorized after a power breakdown.
- (9) When keeping pressing UP or DOWN, the frequency will increase or decrease rapidly to a point and then increase or decrease at even speed.
- (10) The value changed by UP or DOWN can be set through PD077 for confirmation of whether it should be memorized or not. For details refer to Pd077.

6. Function Description of Counter:



Note :

- (1) The signal width triggered should not be lower than 2 msec ($t1, t2 \geq 2\text{msec}$).
- (2) When the counting value reaches the corresponding multi-output contact will act.
- (3) This counter can only count again after reset.
- (4) When reaching to 65535 the counter will not count again.

PD050	Y1-input Function	Factory Setting: 01
PD051	Y2-input Function	Factory Setting: 05
PD052	FA, FB, FG Input Function	Factory Setting: 03
PD053	Ka, KB Input Function	Factory Setting: 00

Set Range: 00-32 Unit: 1

01: In Run: The contact will act when the inverter has output receives the running command.

02: Zero Speed: The contact will act when the output frequency of the inverter is less than its starting frequency.

03: Fault Indication: The contact will act when the inverter detects abnormal conditions.

04: DC Braking Indication: The contact will act when the inverter is in DC braking.

05: Set Frequency Reach: The contact will act when the output frequency of the inverter reaches the set frequency.

06: In Accel: The contact will act when the inverter is in ramp-up.

07: In Decel: The contact will act when the inverter is in ramp-down.

08: Uniform Frequency 1 Reach: The contact will act when the output frequency of the inverter reaches the designated frequency(PD060).

09: Uniform Frequency 2 Reach: The contact will act when the output frequency of the inverter reaches the designated frequency(PD061).

10: Motor Overload Alarm: The contact will act when the inverter detects over-load of the motor.




使用说明书

- 11: Over-torque Detect: The contact will act when the inverter detects over-torque.
 12: Inverter Over-load Alarm: The contact will act when the inverter detects over-load.
 13: Set Counter Reach: The contact will act when the inverter implements the external counter and the counting value is equal to the set value (PD065).
 14: Middle Counter Reach: The contact will act when the inverter implements the external counter and the counting value is greater than or equal to the set value (PD066).
 15: External Control Timer 1 reach: The contact will act when the timer 1 reaches the set value..
 16: External Control Timer 2 reach: The contact will act when the timer 2 reaches the set value
 17: Low Voltage Alarm: The contact will act when the inverter detects low voltage.
 18: Single Step End: The contact will act and generate one pulse when the inverter finishes a single step in implementation of program operation.
 19: Process End: The contact will act and generate one pulse when the inverter finishes all the steps(i.e. after one cycle) in implementation of program operation
 20: 4~20mA Disconnected: When AI input signal is disconnected and PD072 more than 2, the contact will act.
 25: Auxiliary Pump 1: This contact controls the starting and stopping of auxiliary pumps. For details refer to Operation of Multi-pumps.
 26: Auxiliary Pump 2
 27: Drawing reach: The contact will act when the drawing action is finished. The contact will automatically reset when the inverter stops.
 28: PID Lower Limit/Alarm: This contact will act when the PID feedback is smaller than the lower limit (the set value of PD162).
 29: PID Upper Limit/Alarm: This contact will act when the PID feedback is greater than the upper limit (the set value of PD161).
 30: Braking Resistor Act: When the inverter is in running and the DC voltage reaches the braking voltage the contact will act.
 31: Electromagnetic Relay Act: When the contactpuls in, the corresponding multi-function terminal will act.
 32: Fan act: When the temperature of the inverter is increased or it is in running, this contact will act.


PD055	V _o Analog Output Gain	Unit: 0~100. 0%	Factory Setting: 1
This parameter can be used to adjust the output voltage value of Multi-output 6 to adapt to frequency meters with different measuring range and also used to correct a frequency meter. For example, for an externally connected frequency meter with the measuring range of 0~5V, a multi-function terminal can be used to display its operating frequency. Then it can be corrected with this parameter. It can be achieved by setting PD055=50.			

PD056	Skip Frequency 1	Unit: 0.01Hz	Factory Setting: 0.0
PD057	Skip Frequency 2		
PD058	Skip Frequency 3		
Set Range: 0.00~400.00 Hz			
PD059	Skip Frequency Range		
Set Range: 0.10~2.00 Hz			
	Unit: 0.01Hz	Unit: 0.01Hz	Factory Setting: 0.5



These three frequency skipping points are set for avoiding a mechanical resonance point. In case of PD059=0, all skip frequencies are invalid. The actual skip frequency range is two times that of PD059, as shown in the above diagram.

PD060	Uniform Frequency 1	Unit: 0.01 Hz	Factory Setting: 0.00
PD061	Uniform Frequency 2		
Set Range: 0.00~400.00 Hz			
Pd062	Uniform Frequency Range		
Set Range: 0.10~10.00 Hz			
	Unit: 0.01 Hz	Unit: 0.01 Hz	Factory Setting: 0.50



Functions: Output terminal of digital frequency, generating pulse or 0~10V analog. In combination with Pd055 it can be connected with a corresponding instrument with the measuring range below 10 to be used for external monitoring.
 0: 0~10V analog output, corresponding to output frequency 0~1000Hz
 1: 0~10V analog output, corresponding to output current 0~1000mA
 2: Analog output, corresponding to DC bus voltage, 0~10V corresponds to 0~1000V.
 3: Analog output, corresponding to AC output voltage, 0~10V corresponds to 0~510V/255V.
 (Note: The machine type of three phase, 380V corresponds to 510V and the machine type of single phase, 220V corresponds to 255V)

PD054	V _o Input	Unit: 1	Factory Setting: 0
Set Range: 0~7			




使用说明书

Refer to PD065.

When the output frequency is more than the uniform frequency, the corresponding multi-outputs will act.
The uniform frequency range acts as a hysteresis loop.
When the inverter is in the operation of multi-pumps, PD060 is used as high speed frequency and PD061 is set as low speed operating frequency. The definitions of the corresponding multi-function contacts are changed.

PD063 Timer 1 Time Set Range: 0..1~10.00	Unit: 1	Factory Setting: 0.1
PD064 Timer 2 Time Set Range: 1~100	Unit: 1	Factory Setting: 1

Timer 1 is a timer of 0.1s~10.0s and Timer 2 is a timer of 1s~100s. When the timer starts at multi-inputs is closed (on) the timer starts to count time. When it reaches the set time the corresponding multi-output contact will act. When the timer start is opened (off) the timer time at the multi-output will be reset.



Pd063

For example, set PD063=5.0s. When the external control terminal (Multi-Input) is valid the output terminal will be valid after five (5.0) seconds, the signal of which can be used to control other corresponding signals.

PD065 Counting Value Set Range: 0..65500	Unit: 1	Factory Setting: 0
---	---------	--------------------

An external terminal of multi-function can be used as a trigger for the counter. When the counter reaches the set value of PD065 the corresponding multi-output contact will act. After the counter is cleared and reset it will start counting again. A proximity switch or optoelectronic switch can be used for the triggering signals.

PD066 Intermediate Counter Set Range: -65500	Unit: 1	Factory Setting: 0
---	---------	--------------------

PD067 PD069	Reserved
-------------	----------

PD070 Analog Input Set Range: 0~4	Unit: 1	Factory Setting: 1
0: 0~10V 1: 0~5V 2: 0~20mA 3: 4~20mA 4: 0~10V 4~20mA Stacked		

This parameter can be set for different analog input signals.
When PD070=4, the output frequency = $1/2 \times (U/U_{max} - I/I_{max}) \times 50\text{Hz}$
Among which, U: Analog Voltage; Umax: Maximum Analog Voltage;
I: Analog Current; Imax: Maximum Analog Current.

PD071 Analog Filtering Constant Set Range: 0~50	Unit: 1	Factory Setting: 20
--	---------	---------------------

The setting of this parameter is related to the analog responding speed. The higher the value of PD071 is, the lower the analog responding speed will be.

PD072 Higher Analog Frequency Set Range: 0..00..400.00 Hz	Unit: 0.01Hz	Factory Setting: 50.00
PD073 Lower Analog Frequency Set Range: 0..00..400.00 Hz	Unit: 0.01Hz	Factory Setting: 0.00
PD074 Bias Direction at Higher Frequency Set Range: 0..1	Unit: 1	Factory Setting:
PD075 Bias Direction at Lower Frequency Set Range: 0..1	Unit: 1	Factory Setting:

0: Positive direction


1: Negative direction

Bias direction means the instruction of FOR/REV rotation command. Positive bias indicates forward rotation while negative bias indicates reverse rotation. For details refer to the diagram in Pd076.

PD076 Analog Negative Bias Reverse Set Range: 0~1	Unit: 1	Factory Setting:
--	---------	------------------

0: Negative bias Rev is not allowable.
1: Negative bias Rev is allowable.

The parameter group is set for the measuring range and zero point of the external analog terminals and can be combined for any kind of curve to control the operation of the motor.




Setting: PD073=50 PD075=1 PD074=0 PD076=1

Note: this curve can be easily used in complicated applications in combination with other curves. When using the instruction of FOR/REV run from external terminals is still valid. When switching, the curve will turn reverse.




使用说明书

Setting: PD073=50 PD075=1 PD072=50
PD074=0 PD076=1
Note: this curve is a kind of special application of reverse ramp setting. When using transmitter for the control of pressure, temperature and others and while the control has higher pressure and output signals but requiring the corresponding commands of stop or deceleration on the inverter this curve can satisfy the demand properly.



Setting: PD073=50 PD075=1 PD072=50
PD074=0 PD076=1
Note: this method is used extensively. The user can use it flexibly.



Setting: PD073=10 PD075=1 PD072=40
PD074=0 PD076=0

Note: the signal of 0Hz-40Hz (4-4.8mA) is invalid. It can be used to avoid noise disturbance in harsh environment. It is better not to use signals below 1V for setting the operating frequency of the inverter.

0
4mA 4.8mA 20mA
2V-10V(4.8mA-20mA)

PD077 UP/DOWN Function		Unit: 1	Factory Setting: 0
Set Range:	0-1		

0: Not memorized: Memorized This parameter can be set for the selection of whether the values changed by the UP or DOWN shall be memorized or not after stop. The changed values whether to be memorized or not means when they are changed by UP or DOWN during operation and the inverter is restarted after stop these changed values shall be memorized or not after restart. When PD077 is set to 0, the changed value will not be memorized and when it is set to 1, the changed values will be memorized. The set values of PD003 will be memorized after restart.
For the related parameters refer to PD044-PD049.

- | | | |
|----------------------------|----------------|---------------------------|
| PD078 UP/DOWN Speed | Unit: 1 | Factory Setting: 0 |
| Set Range: 0-1 | | |
- ① 0.01Hz. Minimum UP/DOWN speed is 0.01Hz.
 - ② 0.1Hz. Minimum UP/DOWN speed is 0.1Hz.
 - ③ Through the changes of this set value the UP/DOWN speed unit can be adjusted to meet the needs of different customers.

PD079 Reserved

PD080 PLC Operation	Unit: 1	Factor Setting: 0
Set Range: 0-5		

0: Normal operation, i.e. the inverter is running in the normal control mode.
1: Internal control Multi-speeds(16-speeds)

- ① Main speed and 7-speeds compose 8-speeds.
- ② The ramp time of each speed step is set by PD084-PD085.
- ③ Running Time is set by TimerPD101~PD116. For the control steps not to be used the timer can be set to 0.
- ④ Running direction of each speed step is determined by PD082-PD083.
- ⑤ In the internal control multi-speed operation the running time and direction are determined by the setting of internal parameters. Any switching of external time and FOR/REV rotation is invalid.


- 2:External control 4-Speeds (Refer to the function description and diagram of three terminals of high, middle and low speed in PD044~PD049).
- 3: External control Multi-speeds

Multi-function Terminals			Results
Multi-speed 1	Multi-speed 2	Multi-speed 3	
OFF	OFF	OFF	Main frequency and frequencies are determined by PD003 or potentiometer.
ON	OFF	OFF	Multi-speed 1 and frequency are determined by PD086.
OFF	ON	OFF	Multi-speed 2 and frequency are determined by PD087.
ON	ON	OFF	Multi-speed 3 and frequency are determined by PD088.
OFF	OFF	ON	Multi-speed 4 and frequency are determined by PD089.
ON	OFF	ON	Multi-speed 5 and frequency are determined by PD090.
OFF	ON	ON	Multi-speed 6 and frequency are determined by PD091.
ON	ON	ON	Multi-speed 7 and frequency are determined by PD092.

- Note:**
 - ① It is only valid to realize the external control 8-Speeds operation when Multi-inputs are set for Multi-speed 1,2,3 and PD080 is set to 3.
 - ② Multi-speed 1,2,3 can be used to make up 7-Speeds and 8-Speeds adding the main frequency .
 - ③ The frequencies of Speed Step 1 ~ Step 7 are determined by PD086-PD092.
 - ④ Each ramp time is determined by the external multi-function terminal D1-D6.
 - ⑤ The directions of each program operation are determined by the external multi-function terminals D1-D6.
 - ⑥ The main frequency can be set in two ways. One method is to set it through PD003 and another is to set it through the potentiometer. When PD002 is set to 1 the frequency of Main Frequency is set by the potentiometer. For the related parameters refer to PD003, PD002 and PD086-PD092.



4: Drawing
This is a special parameter for the constant speed of unwinding and rewinding. By using this function the linear speed constant in certain accuracy can be realized.

**Note:**


- ① Through triggering of the external multi-function terminal the drawing action begins.
- ② In implementation of the drawing action the actual running time is $T = P \cdot D101 \times 10$.
- ③ when the drawing action is finished the inverter will run at the constant speed of Pd087 and the corresponding multi-output contact will act at the same time. Until receiving the STOP command the inverter will stop running and the multi-output contact will reset.

- 5: Disturbance (Traverse function)
This is a special parameter in the chemical fiber and printing and dying industries to realize the traverse function. Except the commands of stop, external faults and emergency stop all other commands are not accepted at running.

- ① The Frequency at each inflection point is determined by Pd003 and Pd086.
② Skip Frequency is determined by Pd092.
③ Running Time is determined by Timer PD101 and PD102.
④ The related parameters: Pd003, Pd086-PD116.

Explanation:
1. Stop after the program runs one cycle.
When the command of auto program operation is given, the inverter will run with each set value of internal parameters. It will run for one cycle and then stop automatically. The inverter will not restart and run until it receives another command of operation.

2. Cycling run.
When the command of operation is given, the inverter will run in sequence with the frequency of every speed step and running time set by each of the internal parameters and will recycle. During the cycling run, except the commands of stop, external faults and emergency stop, all other commands will not be accepted.
3. Stop after it runs one cycle automatically (STOP for intervention)

**Note:**

- ① When the command of auto program operation is given the inverter will run with each parameters. But it will stop first and then restart at changing of each step and will stop automatically after running for one cycle. The inverter will not restart and run until it receives another command of operation.
- ② The frequencies of each speed step are set by Pd003 and Pd086~Pd092.
- ③ The running times of each speed step are set by Pd101~PD108.
- ④ The running direction is set by P082.

P082 PLC Running Direction of the Front 8-Speeds
P083 PLC Running Direction of the Follow 8-Speeds
Set Range: 0-255 Unit: 1 Factory Setting: 0

P081 Auto PLC
Set Range: 0-3 Unit: 1 Factory Setting: 0

This parameter is only valid when Pd000 is set to 1. This parameter setting determines the running direction of each frequency of Pd086~Pd092 and Pd003 in the program operation. The setting method is as follows:
The rotation direction is set first in the binary 8 bits mode, and then converted to a value for the setting of this parameter. For instance:
The parameter value 01001010 is converted to a decimal value:
$$\begin{aligned} & 1 \times 2^7 + 1 \times 2^5 + 1 \times 2^3 + 1 \times 2^2 + 1 \times 2^1 + 1 \times 2^0 = 64 + 32 + 16 + 8 + 4 + 2 + 1 \\ & \text{Then } P081=74 \end{aligned}$$

Pd083 means that set running direction of the follow 8-speeds (the algorithm likes Pd082)

P084 Ramp Time of the Front 8-Speeds



使用说明书

PD085 Ramp Time of the Follow 8-Speeds Set Range: 0~65535	Unit: 1S	Factory Setting: 0
--	----------	--------------------

This parameter is only valid when PD080 is set to 1.
This parameter is set to determine the ramp time values for the internal control multi-speed and each speed. The setting method is as follows:

① Determine each Ramp Time in the binary 2 bit mode

Bit1	Bit0	Ramp Time
0	0	Ramp Time 1 PD014, PD015
0	1	Ramp Time 2 PD016, PD017
1	0	Ramp Time 3 PD018, PD019
1	1	Ramp Time 4 PD020, PD021

② Determine the Ramp time of each speed step in the binary 16 bit mode

Step 8	Step 7	Step 6	Step 5	Step 4	Step 3	Step 2	Step 1
t8	t7	t6	t5	t4	t3	t2	t1
0	0	0	0	b	0	0	1

t1 Select Ramp Time4
t2 Select Ramp Time1
t3 Select Ramp Time 3
t4 Select Ramp Time 2
t5 Select Ramp Time 1
t6 Select Ramp Time 1
t7 Select Ramp Time 1
t8 Select Ramp Time1

The setting value:
 $1 \times 2^0 + 1 \times 2^1 + 1 \times 2^5 + 1 \times 2^8 = 99$
So PD084 is set to 99
Attach: $2^0 = 1$ $2^1 = 2$ $2^5 = 4$ $2^8 = 256$
 $2^0 = 1$ $2^1 = 2$ $2^5 = 32$ $2^8 = 128$

PD085 means that set ramp time of the follow 8-speeds(the algorithm likes Pd084)

PD086 Frequency 2	Factory Setting 15
PD087 Frequency 3	Factory Setting 20
PD088 Frequency 4	Factory Setting 25
PD089 Frequency 5	Factory Setting 30
PD090 Frequency 6	Factory Setting 35
PD091 Frequency 7	Factory Setting 40
PD092 Frequency 8	Factory Setting 0.5

PD117 Internal Control Multi-Speeds Memory Function	Set Range: 0~1	Factory Setting: 0
---	----------------	--------------------

- 0: Not memorized
1: Memorized

PD093 Frequency 9	Factory Setting 10
PD094 Frequency 10	Factory Setting 15
PD095 Frequency 11	Factory Setting 20
PD096 Frequency 12	Factory Setting 25
PD097 Frequency 13	Factory Setting 30
PD098 Frequency 14	Factory Setting 35
PD099 Frequency 15	Factory Setting 40
PD100 Frequency 16	Factory Setting 45

Set Range: 0.00~400.00 Hz
Unit: 0.01 Hz

This parameter is set for cooperate the multi-terminals, can choose the external 4-speeds the external control multi-speeds and the internal control multi-speeds. For the relevant parameter refer to PD080 and PD086~PD100

PD101 Timer 1	Factory Setting 10.0
PD102 Timer 2	Factory Setting 10.0
PD103 Timer 3	Factory Setting 0.0
PD104 Timer 4	Factory Setting 0.0
PD105 Timer 5	Factory Setting 0.0
PD106 Timer 6	Factory Setting 0.0
PD107 Timer 7	Factory Setting 0.0
Pd108 Timer 8	Factory Setting 0.0
PD109 Timer 9	Factory Setting 0.0
PD110 Timer 10	Factory Setting 0.0
PD111 Timer 11	Factory Setting 0.0
PD112 Timer 12	Factory Setting 0.0
PD113 Timer 13	Factory Setting 0.0
PD114 Timer 14	Factory Setting 0.0
PD115 Timer 15	Factory Setting 0.0
PD116 Timer 16	Factory Setting 0.0

Set Range: 0.06500.00

This parameter is set for the internal control multi-speeds and the running time of drawing function.
For the relevant parameter refer to PD080 and PD101~PD116.



使用说明书

This parameter is set to determine whether the inverter is to realize the suspending function in Auto PLC mode. In case of PD115=1 it can memorize the status in which the inverter is running and will memorize it at stop or fail. It will continue to run when returning to normal. In case of PD115=0 it will not memorize.

- 0: When reaching the frequency it starts to detect over-torque and when over-torque is detected it continues to run.
- 1: When reaching the frequency it starts to detect over-torque and when over-torque is detected it stop running.
- 2: It detects over-torque during running and when over-torque is detected it continues to run.
- 3: It detects over-torque during running and when over-torque is detected it stop running.

PD118	Over-voltage Stall Prevention	Unit: 1	Factory Setting: 1
Set Range:	0~1	Unit:	1

0: Over-voltage stall prevention invalid.
1: Over-voltage stall prevention valid.

When the inverter is in deceleration, due to the effect of load inertia, the motor will produce a return energy to the inverter and cause the DC voltage of the inverter to increase. So when the function of over-voltage stall prevention is started, if the DC voltage of the inverter becomes too high, the inverter will stop decelerating till the voltage at DC decreases below the set value, then the inverter will go onto decelerate and the ramp-down time will be extended automatically.

PD119	Stall Prevention Level I at Ramp-up	Unit: 1%	Factory Setting: 150
Set Range:	0~200%	Unit:	1%

When the inverter is in ramp-up, due to overload or too short ramp-up time, the output current of the inverter will go up quickly and exceed the set standard level. When this happens, the inverter will stop accelerating. When the current returns under its set value, the inverter will go on to accelerate.

100% current is the rated current of the motor. When this parameter is set to 0, the stall prevention function is invalid.

PD120	Stall Prevention Level I at Constant Speed	Unit: 1%	Factory Setting: 0
Set Range:	0~200%	Unit:	1%

When the inverter is running at constant speed, due to load fluctuation and other reasons, the current will increase. When the current exceeds its set standard value, the inverter will lower the output frequency. When the output current returns to its normal range, the inverter will accelerate again to its set frequency.

100% current is the Rated Current of the motor. When this parameter is set to 0 the stall prevention function is invalid.

PD121	Decel. Time for Stall Prevention at Constant Speed	Factory Setting: 5.0
Set Range:	0~200%	Unit:

When the inverter is used for the loads of kinds of fan and pump PD119 can be set to 120. When the current of the inverter is greater than 120% the output frequency will decrease and the current will also decrease accordingly. After the current returns to normal the frequency will return to normal slowly, so as to achieve the stall prevention function. The decreasing speed of the frequency is determined by PD119. For the Related parameters refer to PD119.

PD122	Stall Prevention Level I at Deceleration	Unit: 1	Factory Setting: 150
Set Range:	0~200%	Unit:	1
Refer to Pd120.	100% current is the rated current of the motor.	Unit:	1

PD123 Over-torque Detect Mode
Set Range: 0~3
Factory Setting: 0

- 0: When reaching the frequency it starts to detect over-torque and when over-torque is detected it continues to run.
- 1: When reaching the frequency it starts to detect over-torque and when over-torque is detected it stop running.
- 2: It detects over-torque during running and when over-torque is detected it continues to run.
- 3: It detects over-torque during running and when over-torque is detected it stop running.

PD124	Over-torque Detect Level	Unit: 1%	Factory Setting: 0
Set Range:	0~200%	Unit:	1%

When the output current exceeds the over-torque detection level and also exceeds half of the set time of over-torque detection (factory setting: 1.0s), the over-torque detection will indicate, and the corresponding multi-function alarm contact will act. When it exceeds the settime, the inverter will turn to self-protection. When this parameter is set to 0, the over-torque detection will be invalid.

PD125	Over-torque Detect Time	Unit: 0.1s	Factory Setting: 1.0
Set Range:	0.1~20.0s	Unit:	0.1s

When the inverter detects that the output current has exceeded the motor current set value, the inverter begins to calculate the over-torque time. When the over-torque time has exceeded half of the set detect time, the corresponding multi-function output contact will act, and produce the over-torque alarm, while the inverter will turn to self-protection. When the over-torque time has exceeded the set detect time (set by PD125), For the related parameters refer to Pd123.

PD126	Counter Memory	Unit: 0	Factory Setting: 0
Set Range:	0~1	Unit:	0

The function of counter memory, the function of inverter power-breakdown memory

PD127	PD129 Reserved		
-------	----------------	--	--

PD130	Number of Auxiliary Pump	Unit: 1	Factory Setting: 0
Set Range:	0~2	Unit:	1

This parameter is set for the number of auxiliary pump. The starter stop of the auxiliary pumps is controlled by using themulti-output contacts andAuxiliary Pump 1 or Auxiliary Pump 2 is controlled through the peripheral control circuit.

PD131	Continuous Running Time of Auxiliary Pumps	Unit: 1	Factory Setting: 60
Set Range:	19000 (min)	Unit:	1

In case of two pumps with only one pump in duty, in order to ensure each pump to work evenly, it will be switched to another pump when its running time reaches the set value of Pd131.

PD132	Interlocking Time of Auxiliary Pump	Unit: 1	Factory Setting: 5S
Set Range:	1~250S	Unit:	1

This parameter is set to determine the interlocking time of two auxiliary pumps when switching with each other.




使用说明书

PD138 Sleep Frequency Set Range: 0.00~40.0 Unit: 1 Factory Setting: 20.0	
PD139 Lasting Time of Sleep Frequency Set Range: 1~250S Unit: 1 Factory Setting: 20S	
PD133 High Speed Running Time Set Range: 1~250S Unit: 1 Factory Setting: 60S	
<p>In the application of water supply with constant pressure, when the master pump is running at the frequency of high speed (set by PD060) due to larger water volume and the high speed running time is reached, the corresponding multi-function contacts act and the auxiliary pumps start.</p>	
PD134 Low Speed Running Time Set Range: 1~250S Unit: 1 Factory Setting: 60S	
<p>In the application of water supply with constant pressure, when the master pump is running at the frequency of low speed (set by PD061) due to smaller water volume and the low speed running time (PD134) is reached, the corresponding multi-function contacts act and the auxiliary pumps stop.</p>	
<p>PD133 and PD134 must be used in combination of PD060, PD061 and multi-outputs. Their main function is to increase or decrease the number of auxiliary pump.</p>	
PD141 Rated Motor Voltage Set Range: 0~400V Unit: 1V Factory Setting: *	
<p>This parameter is set for the lasting time for entering into sleep mode.</p>	
PD142 Rated Motor Current Set Range: 0~999A Unit: 1A Factory Setting: *	
<p>It is set according to the rated voltage value of the nameplate of the motor. This parameter can be used to restrict the output current of the inverter to prevent over-current and protect the motor if the current of the motor has exceeded this value.</p>	
PD143 Motor Pole Number Set Range: 0~2~10 Unit: 1 Factory Setting: 0	
<p>This parameter is set for the number of the motor's pole according to the nameplate of the motor.</p>	
PD144 Rated Motor Revolution Set Range: 0~9999 Unit: 1r/min Factory Setting: 1440	
<p>This is set according to the actual revolution of the motor. The displayed value is the same as the set value. It can be used as a monitoring parameter, which is convenient to the user. This set value corresponds to the revolution of 50Hz.</p>	
PD135 Stopping Voltage Level Set Range: 0~150% Unit: 1 Factory Setting: 95%	
<p>This parameter is set for the voltage level of the master pump entering into sleep mode. For details refer to the following description.</p>	
PD136 Lasting Time of Stopping Voltage Level Set Range: 1~250S Unit: 1 Factory Setting: 30S	
<p>This parameter is set for the lasting time under the stopping voltage level before entering into sleep mode. For details refer to the following description.</p>	
PD137 Wakeup Voltage Level Set Range: 1~150% Unit: 1 Factory Setting: 90%	
<p>This parameter is set for the wakeup voltage level from sleep to wakeup.</p>	



使用说明书

0: Invalid, i.e. the inverter will not restart after an instantaneous power breakdown.
1: Start by frequency track. Refer to PD025.



PD146	Motor No-load Current	Set Range: 0~99	Unit: 1	Factory Setting: 40
The setting of motor no-load current will affect the value of slip compensation. The current is 100% of the rated current of the motor.				

PD147	Motor Slip Compensation	Set Range: 0~10.0	Unit: 0.1	Factory Setting: 0.0
When the inverter drives the motor the slip becomes bigger due to the increase of load. This parameter can be set for slip compensation to decrease the slip and make the running speed of the motor closer to the synchronous revolution.				

PD148~PD149	Reserved			
-------------	----------	--	--	--

PD150	Auto Voltage Regulation	Set Range: 0~1	Unit: 1	Factory Setting: 1
-------	-------------------------	----------------	---------	--------------------

0: Invalid 1: Valid	When the input power is not stable and if the voltage is too high the operation of the motor with the power exceeding the rated voltage will cause increase of the temperature of the motor, damage of its insulation and unstable output torque. This auto voltage regulation can automatically stabilize the output voltage within the rated voltage range of the motor under the condition of unstable output power supply. When this function is set to invalid the output voltage will fluctuate.	Unit: 1%	Factory Setting: 0
------------------------	--	----------	--------------------

PD151	Auto Energy Saving	Set Range: 0~10%	Unit: 1%	Factory Setting: 0
-------	--------------------	------------------	----------	--------------------

When it is set to zero this function is invalid. When Auto energy saving function is started the inverter will run at the full voltage during ramp-up or -down. During the operation at constant speed the inverter can automatically calculate the optimum voltage value according to the power offload and supply power to the load to achieve the goal of energy saving.	Unit: 1~10 s	Factory Setting: 1.0 s
---	--------------	------------------------

PD152	Fault Restart Time	Set Range: 0~1	Unit: 1	Factory Setting: 0
-------	--------------------	----------------	---------	--------------------

When the inverter is set for fault restart and if it has a fault trip with the time exceeding the set value of PD153 the inverter will restart. When using this function pay more attention to the safety.	Unit: 1~10 s	Factory Setting: 0
--	--------------	--------------------

PD154	Allowable Power-Breakdown Time	Set Range: 0~15~0 S	Unit: 0.1 S	Factory Setting: 0.5
This parameter is set for the maximum allowable power failure time. If exceeding the set time the inverter will continue to stop output after power on. Restart the inverter it needs to follow the general starting procedures.				
PD155	Number of Abnormal Restart	Set Range: 00~10	Unit: 1	Factory Setting: 00
After the abnormal conditions (such as over-current and over-voltage) happens the inverter will automatically reset and restart. If the starting mode is set to normal mode it will start according to the normal procedures. If it is set to start by frequency track mode it will start in the frequency track mode. After starting it will restore these number again if there is no more abnormality happened within 60 seconds. If there is still an error and it reaches the set number the inverter will stop output. It can only be started after reset. When PD155 is set to zero the inverter will not carry out the functions of automatic reset and restart.				
PD156	Proportional Constant (P)	Set Range: 0~100. 0%	Unit: 0.1%	Factory Setting: 100%
This proportional constant is set for the error value gain. In case of I=0, D=0, it is only for proportional control.				
PD157	Integral Time (I)	Set Range: 0~1~3600. 0s	Unit: 0.1 s	Factory Setting: 5. 0s
The integral time (I) is set for the responding speed for PID. The larger the I value is set the slower the responding speed will be. To the contrary, if the responding speed is quick but the integral time value is set too small, it will cause oscillation.				
PD158	Differential Time (D)	Set Range: 0. 01~10. 00s	Unit: 0. 01s	Factory Setting: 0
This differential time (D) is set for the depression operation of PID. The larger the D value is, the more obvious the depression operation will be. When D is set to zero, this function is invalid.				
PD159	Target Value	Set Range: 0~100. 0%	Unit: 1%	Factory Setting: *
This target value can be set through external voltage signal or the digital operator. 100% target value is corresponding to the analog frequency at +10V.				
PID-closed-loop control is usually used in the process control with physical quantity not changing fast, such as the controls of pressure and temperature, etc. The feedback signal is usually taken from temperature transmitter, or pressure transmitter, etc. Under PID control, the feedback signal path is the analog current signal of 4~20mA.				
PID-closed-loop control is valid when Multi-input PID is started.				
PID Control BlockDiagram:				



使用说明书

When the inverter is set for RS-485 Communication interface control, each of the inverters will be set for its individual identification .


00: No communication function.

01~250: Address for the inverters

PD164	Communication Baud Rate	Unit:	Factory Setting:
Set Range: 0~3			

PD165	Communication Data Method	Unit:	Factory Setting:
Set Range: 0~5			

PD166~PD168	Reserved	Unit:	Factory Setting:
-------------	----------	-------	------------------



PD160	PID Target Value	Unit:	Factory Setting: 0*
Set Range: 0~1			

This function is not available for the inverter of J series.
The target value can be set through the selection of the plane or external analog. The external analog is 0~10V signal origin by the potentiometer.

When PD160=0, the target value of PID is the value set by PD159.

When PD160=1, the target value of PID is the value of the external analog 0~10V (corresponding to 0~100%), the setting of PD159 is invalid.

PD161	PID Upper Limit	Unit:	Factory Setting: 100%
Set Range: 0~100%			

When PID feedback value is more than the set value of PD161, the corresponding multi-output will act and the inverter will not stop.

PD162	PID Lower Limit	Unit:	Factory Setting: 0%
Set Range: 0~100%			

When PID feedback value is less than the set value of PD162, the corresponding multi-output will act and the inverter will not stop.

PD163	Communication Addresses	Unit:	Factory Setting: 00
Set Range: 00~250			

It is factory setting. It is depending on the model. It can be observed, but not set.

General operating methods of PID control:

- (1) Choose the correct transmitter (with the output specification of standard current signal 4~20mA).
- (2) Set the right target value.
- (3) If the output does not have oscillation, increase the proportional constant (P).
- (4) If the output does not have oscillation, decrease the integral time (T).
- (5) If the output do no have oscillation, increase the differential time (Td).
- (6) Concrete applications can be referred to the example application descriptions in Appendix I.

When the inverter is set for RS-485 Communication interface control, each of the inverters will be set for its individual identification .

00: No communication function.

01~250: Address for the inverters

PD164	Communication Baud Rate	Unit:	Factory Setting:
Set Range: 0~3			

PD165	Communication Data Method	Unit:	Factory Setting:
Set Range: 0~5			

PD166~PD168	Reserved	Unit:	Factory Setting:
-------------	----------	-------	------------------

PD170	Display Items	Unit:	Factory Setting:
Set Range: 0~5			

PD171	Display Items Open	Unit:	Factory Setting:
Set Range: 0~15			

PD172	Fault Clear	Unit:	Factory Setting:
Set Range: 0~10			

PD173	Voltage Rating of Inverter	Unit:	Factory Setting: *
Set Range: 0~250			


This parameter is only valid when Bit2 is set to 1 in PD171. For the details refer to PD171.

0: Inverter Temperature

1: Counter Value

2: PID Target Value

3: PID Feedback Value



Select to display items of Pd170.

This parameter is set for selection of displaying of DC voltage, AC voltage and other items so that the customer can monitor and view them in sequence through the switchkey. It can be set first in the binary's bits mode, and then converted to a decimal value.

This parameter is set for selection of displaying of DC voltage, AC voltage and other items so that the customer can monitor and view them in sequence through the switchkey.

It can be set first in the binary's bits mode, and then converted to a decimal value.



X. Care & Maintenance, Fault Information and Troubleshooting

Periodical maintenances and inspections will keep your inverter in its normal state for long time.

PD174	Rated Current of Inverter It is depending on the model and can't be changed.	Unit: 1A	Factory Setting: *
PD175	Inverter Mode Set Range: 0~1	Unit: 1	Factory Setting: 0
0: Constant torque 1: For kinds of fan. It can be observed, but not changed.			
PD176	Inverter Frequency Standard Unit: 1	Factory Setting: *	
0: 50Hz 1: 60Hz	It is factory setting. It can be observed, but not set.		
PD177	Fault Record 1	Factory Setting:	
PD178	Fault Record 2	Factory Setting:	
PD179	Fault Record 3	Factory Setting:	
PD180	Fault Record 4	Factory Setting:	
PD181	Software Version	Factory Setting: *	
PD182	Manufacture date	Factory Setting: *	
PD183	Serial No.	Factory Setting: *	
	It is observed, but not set.		
PD183~PD250	Factory Setting: *		

Note:
* means the said parameter has a variety of set values or should be set specifically according to concrete conditions.
** means the said parameter can be set during the operation.

1. Precautions about Inspection and Maintenance

- Be sure to turn off the power supply to the inverter (R.S.T) first before the inspection and maintenance.
- After confirming the main circuit power supply has been turned off and the display has disappeared, wait until the internal indicator lamp for high voltage goes out before performing the inspection and maintenance.
- During the inspection, do not pull out or strongly distribute the internal power supply wires and cables. Otherwise it will cause malfunction or damage to the inverter.
- Do not leave any screw or other part inside the inverter during the installation, or it will result in the short circuit of circuit board.
- Keep the inverter clean, free from dust, oil mist and moisture after the installation.

2. Periodical Inspection and Maintenance Items

- Check whether the power supply voltage conforms to the rated voltage of the inverter.
(Pay special attention to that whether there is any damage on the power supply wires and the motor.)
- Check whether the wiring terminals and the connectors are tight.
(Check whether the power supply wires and terminal connection wires have any broken strand).
- Check whether there is dust, iron filings or corrosive fluid in the inverter.
- Measuring the insulation impedance of the inverter is forbidden.
- Examine the output voltage, output current and output frequency of the inverter.
(The measuring results should not have too big difference.)
- Check whether the ambient temperature of the inverter is between -5°C and 40°C and whether the installation environment has good ventilation.
- Check whether the humidity is kept below 90% (without condensation).
- Check whether the motor makes unusual noises or abnormal vibration in running.
(The inverter should not be installed in a place with high vibration.)
- Please make periodical cleaning of vent holes.

3. Fault Indication and Troubleshooting

The inverter of HLP series is relatively perfect with the protection functions of overload, inter-phase short circuit, earth short circuit, under-voltage, overheating and over-current, etc. When a protection function happens with the inverter please check the reasons of faults according to the information listed in the table below. The inverter can be restarted after the disposal if the fault cannot be disposed please contact the local distributor.

Fault Display	Fault Contents & Description	Disposal methods
E,LL,R	Over-current during ramp-up	1: Check whether the motor has got short circuit or partial short circuit and whether the insulation of output wire is good. 2: Extend the ramp-up time. 3: The configuration of the inverter is not reasonable. The inverter's capacity should be increased. 4: Decrease the torque and increase the set value.



E.O[.n]	Over-current at constant speed Over-current at stop Over-current at decel	E.OH.R E.OI.R E.OU.R E.OF.R E.OV.R	Overheat of inverter	1: Check whether the fan has got short circuit and whether the insulation of the output wires is good. 2: Check whether the motor is blocked and whether there is sudden change of mechanical load. 3: Check whether the inverter's capacity is too small and increase its capacity. 4: Check whether there is a sudden change in the power supply voltage.:.	1: Check whether the fan is blocked and whether there is any foreign matter stuck in the cooling fins. 2: Check whether the ambient temperature is normal. 3: Check whether there is enough space for ventilation and good air convection.
				E.OI.R E.OU.R E.OV.R	1: Check whether the capacity of the inverter is lower. Otherwise it should be increased. 2: Check whether there is any jamming in the mechanical load. 3: The setting of V/F curve is bad. Set it again.
E.O[.d]	Short circuit to earth	E.OF.S E.OF.R E.OF.N E.OF.D	Inverter over-load 150% Per minute	E.OH.R E.OI.R E.OU.R E.OV.R	1: Check whether there is any sudden change in the mechanical load. 2: The equipped motor is too small. 3: The motor is hot and the insulation becomes bad. 4: Check whether the voltage has big fluctuation. 5: Check whether there is any phase missing. 6: The mechanical load is increased.
				E.OH.R E.OI.R E.OU.R E.OV.R	1: Check whether there is any sudden change in the mechanical load. 2: Check whether the equipped motor is smaller.
E.O[.d]	Over-voltage at stop Over-voltage at constant speed Over-voltage at decel	E.OU.S E.OU.R E.OU.N E.OU.D	Motor over-torque	E.OH.R E.OI.R E.OU.R E.OV.R	1: Check whether there is any fluctuation in the mechanical load. 2: Check whether the equipped motor is smaller.
				E.OH.R E.OI.R E.OU.R E.OV.R	No feedback from auxiliary coil of the electromagnetic contactor Please contact the factory
E.O[.d]	Over-voltage at stop Over-voltage at constant speed Over-voltage at decel	E.OU.S E.OU.R E.OU.N E.OU.D	Braking transistor damage Please send it for repair.	E.OH.R E.OI.R E.OU.R E.OV.R	Braking transistor damage Please send it for repair.
				E.OH.R E.OI.R E.OU.R E.OV.R	CPU fault Please contact the factory
E.O[.d]	Low voltage	E.OU.S E.OU.R E.OU.N E.OU.D	CPU fault Please contact the factory	E.OH.R E.OI.R E.OU.R E.OV.R	E ² Prom fault Please contact the factory
				E.OH.R E.OI.R E.OU.R E.OV.R	



(3) The motor cannot rotate reverse.

Reverse rotation is disabled.

(4) The motor rotates in the opposite direction.

The output line is wrongly connected. Please change any two lines of U,V,W over.

(5) The deceleration of the motor is too slow.

- 1) The setting of Ramp-down Time is too long. Decrease Ramp-down Time.
- 2) Add a braking resistor.
- 3) Add a DC brake.

(6) Over-heat of the motor

The load is too large. The actual torque has exceeded the rated torque of the motor. It is recommended to increase the capacity of the motor.

- 1) The ambient temperature is too high. In a place with higher temperature the motor will be burn out. Please decrease the temperature around the motor.
- 2) The phase to ground voltage is too high. The switch actions of the inverter will make the winding coil of the motor produce shock wave.
- 3) The phase to ground voltage is too low. The switch actions of the inverter will make the winding coil of the motor produce shock wave.

Typically the maximum shock voltage will reach 3 times of the input power of the inverter. Please select a motor with higher phase to ground voltage against shock than the maximum shock voltage.

(7) The starting of the inverter interferes other control devices

- 1) Decrease the carrier frequency and reduce the number of actions of internal switches.
- 2) Install a noise filter at the power input of the inverter.
- 3) Install a noise filter at the output of the inverter.
- 4) Make correct grounding for the inverter and the motor.
- 5) Use metal conduit tube the cable to shield it.
- 6) Make separate wiring for the main circuit wires and control wires.

(8) When the fan starts the inverter detected an over-current stall.

- 1) At start the fan rotates idly. Please set it for DC-braking at start.
- 2) When DC-braking at start has been set increase the DC-braking value.

(9) The machine has the noise of vibration or roar

- 1) The vibration frequency of mechanical system resonates with the carrier. Adjust the carrier to avoid the point of resonance.
- 2) The vibration frequency of mechanical system resonates with the output frequency of the inverter.
- A. Set it for skip function to avoid the point of resonance.
- B. Put rubber vibration isolators on the base plate of motor.

4. Faults and Analysis

(1) When RUN key is pressed, the motor does not run.

- 1) The setting of operation mode is wrong, i.e., under the operation mode of the digital operator it is started by the external control terminals.
- 2) The frequency reference is too low or not set.
- 3) The peripheral wiring is wrong. For example, the setting of wiring of two-wire system and three-wire system and other related parameters have errors.
- 4) The setting of multi-function terminals is wrong (in the external control).
- 5) The inverter is in the fault protection.
- 6) The motor fails.
- 7) The inverter fails.

(2) The parameters cannot be set.

- 1) Password locks. Please decrypt it first before resetting.
- 2) The inverter is in running.
- 3) The connection of the connecting parts is abnormal. The communication of the digital operator is abnormal. Take out the operator after power-off and then mount it again for a trial.

Er	External interferences	Isolate the interference source
ES	Emergency Stop	In Emergency Stop
20	4~20mAz wire broken	Join the broken wires
Pr	Setting error	Correct the setting
Deb	DG-braking status	DG-braking

Note:

(1) Fault Code Form as follows:



(2) Code Comparison Table

	B	C	D	E	F	G	H	O	S	N	L	T	P	R	U	2
	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□

(3) When the RUN key is pressed, the motor does not run.

- 1) The setting of operation mode is wrong, i.e., under the operation mode of the digital operator it is started by the external control terminals.
- 2) The frequency reference is too low or not set.
- 3) The peripheral wiring is wrong. For example, the setting of wiring of two-wire system and three-wire system and other related parameters have errors.
- 4) The setting of multi-function terminals is wrong (in the external control).
- 5) The inverter is in the fault protection.
- 6) The motor fails.
- 7) The inverter fails.

(4) The parameters cannot be set.

- 1) Password locks. Please decrypt it first before resetting.
- 2) The inverter is in running.
- 3) The connection of the connecting parts is abnormal. The communication of the digital operator is abnormal. Take out the operator after power-off and then mount it again for a trial.

Description	Functions
NFB or Ground fault interrupter for wire connection	Protect the wiring of the inverter. Be sure to install a breaker at the power. Please select a ground fault circuit interrupter against high-order harmonics.
Electromagnetic contactor	In order to prevent the braking resistor from burning out, please add an electromagnetic contactor and connect a surge absorber to the coil when using it.



使用说明书

Surge absorber	Absorb the switching surge current from the electromagnetic contactor and control relays.
Isolating transformer	Its function of isolating the input and output of the inverter is effective to reduce the interference to other electric devices.
DC reactor	Improve the input power factor of the inverter.
AC reactor	Improve the input power factor of the inverter and prevent the shock of surge voltage.
Braking resistor braking unit	Consume the regenerating energy of the motor and shorten the ramp-down time.
1) Leakage switch	There is earth static capacity inside of the inverter and the motor as well as the input and output leads. Due to higher carrier frequency of the inverter, the inverter has higher earth leakage current, especially for the inverters of large capacity series. When using a leakage switch, it may sometimes result in the erraction of the protective circuit. So when using a leakage switch, attention should be paid to its selection and the proper reduction of carrier frequency and shortening the leads, etc.
2) AC reactors	An AC reactor can construct the high-order harmonic of input current of the inverter to improve its input power factor and prevent the shock of surge. It is recommended to use an input AC reactor under the following circumstances: a: Three-phase power supply is in unbalance. b: Any equipment with thyristor or power factor compensation unit with switching controls connected to the same power supply.
3) DC reactors	It is necessary to install a DC reactor when the capacity of power supply is more than 1000 KVA or the mains power capacity is higher than the rated capacity of the inverter. A DC reactor is also needed for the case with higher demand on the improvement of power factor of power supply. This DC reactor can be used together with an AC reactor to achieve the obvious effect of decreasing high-order harmonic at input. If it is necessary to install a DC reactor please contact the local distributor.

Disposition of Braking Resistor

For the inverter of above 11kW to realize quick brake a braking unit must be added.

Inverter Model	Braking resistor Specification W	Braking torque 10%ED Ω	Special Motor KW
HY00D423B	80	200	0.4
HY0D7523B	100	200	0.75
HY01D523B	300	100	1.5
HY02D223B	300	70	2.2
HY0D7543B	80	750	0.75
HY01D43B	300	400	1.5
HY02D243B	300	250	2.2

- Note:**
- 1: Please select the resistor value and operating frequency given by our company.
 - 2: If it causes any damage to the inverter and other devices due to the use of any braking resistor and braking model group not supplied by our company, we will take no responsibility.
 - 3: Be sure to consider the safety and dignitability of the environment when installing a braking resistor.
 - 4: The distance to the inverter should be at least 100 mm.
 - 5: If it is necessary to change the resistor value and power value, please contact the local distributor. In need of a braking resistor a separate order must be placed. Please contact the local distributor for details.



使用说明书

User Parameter Set

Par. No.	Function Name	User Set Value

Note:
The Engineer is highly appreciated to fill the form above carefully and
detailedly in order to be easily readjusted by the end customers.

Engineer name:
Telephone No.:
Installing Date: